


KitchenAid®

COOKTOP PARTS

For Model: KGRT507FWH0, KGRT507FAL0, KGRT507FBL0
(White) (Almond) (Black)

30" Freestanding
Gas Range
DESIGNER STYLE
Convection Oven




NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1		Cooktop, Ceran
	9752625CW	White
	9752625CT	Almond
	9752625CB	Black
2	9780939	Gasket, Cooktop
3		Trim, Cooktop (Right Hand)
	9751275PT	Almond
	9751275PW	White
	9751275PB	Black
		Trim, Cooktop (Left Hand)
	9751276PT	Almond
	9751276PW	White
	9751276PB	Black
4		Gasket, Cooktop
	9752029	Grey
	9752026	Black
	9752028	Almond
5	9752632	Support, Element
6	9751629	Bracket, Pivot
	9780265	Screw, (2)
7	9750866	Holder, Starter
8	9750821	Support Clips (4)
	9751871	Screw (4)
9		Cover, Light
	9751327	White
	9751633	Almond
	9751632	Black
10		Backsplash
	9751266GB	Black
	9751266GW	White
	9751266GT	Almond
	9780265	Screw (5)
11		Bezel, Small LR-RF
	9752624GS	Gray
	9752624GB	Black
12		Bezel, Large RR-LF
	9752623GS	Gray
	9752623GB	Black
13		Grate, 2 Burner
	9752665CS	Gray
	9752665CB	Black
15	9752638	Pad, Grate (4)
16		Cap, Small (2)
	9752667GS	Gray
	9752667GB	Black
17	341196	Thermo-Disc
	9780265	Screw, (2)
18		Cap, Vent
	9751271GW	White Mdl.
	9751271GT	Almond Mdl.
	9751271GB	Black Mdl.
19	9751366	Cap, Vent
20	9751984	Fuse, Bi-Metal
21		Cap, Large (2)

	9752666GS	Gray
	9752666GB	Black
22	9752006	Thermostat, Fixed
23	9752034	Seal, Rubber (2)
24	9750273	Receptacle, Lamp
25	422581	Lamp, Fluorescent
26	9751664	Cover, Backsplash
	3149333	Screw (5) #10AB x 3/8
27		Endcap, Backsplash (Right Hand)
	9751268FB	Black
	9751268FW	White
	9751268FT	Almond
		Endcap, Backsplash (Left Hand)
	9751267FB	Black
	9751267FW	White
	9751267FT	Almond
28	9781154	Glass, Backsplash
29	9781118	Starter, Light

COOKTOP BURNER PARTS


For Model: KGRT507FWH0, KGRT507FAL0, KGRT507FBL0
(White) (Almond) (Black)



1		Burner, Surface
	9752641	Small RF-LR
	9752640	Large LF-RR
2	9752649	Tubing, Burner (RF)
3	9752650	Tubing, Burner (RR)
4	9752647	Tubing, Burner (LF)
5	9752648	Tubing, Burner (LR)
6	9752646	Tubing, Manifold (Left)
7		Valve, Burner
	9751333	Small (2)
8		Valve, Burner
	9751334	Large (2)
	3185829	Bolt, Gas Valve (4)
9	9751325	Switch, Ignitor (4)
10	9751285	Tubing, Manifold (Right)
11	9751287	Manifold (2)
12	9751283	Tee, Flare
13	3185804	Electrode
	3185805	Speed nut
16	3185947	Orifice, Small #56
	3185948	Orifice, Large #52
18	9751854	Tubing, Flex
19	9781457	Bracket, Manifold
20	9752627	Bracket, Burner

CONTROL PANEL PARTS

For Model: KGRT507FWH0, KGRT507FAL0, KGRT507FBL0
(White) (Almond) (Black)




NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1		Console, Glass
	9751888	White Mdl.
	9751894	Black Mdl.
	9751892	Almond Mdl.
2	3191106	Timer, Electronic
	9780271	Screw, (2)
4		End Cap Right Hand
	9751280FW	White
	9751280FT	Almond
	9751280FB	Black
		End Cap Left Hand
	9751279FW	White
	9751279FT	Almond
	9751279FB	Black
	9780265	Screw, (2) 10 x 3/8
8		Knobs, Control
	9751199FW	White Mdl.
	9751199FT	Almond Mdl.
	9751199FF	Black Mdl.
23		Washer, Console (4)
	9751450	White Mdl.
	9751451	Almond Mdl.
	9751449	Black Mdl.

DOOR AND DRAWER PARTS

For Model: KGRT507FWH0, KGRT507FAL0, KGRT507FBL0
(White) (Almond) (Black)




NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	9750676	Retainer, Glass
2		Trim, Door-Left
	4212028	White
	9750631PT	Almond
	4211899	Black
3		Trim, Door-Right
	4212029	White
	9750632PT	Almond
	4211900	Black
4		Trim, Door Bottom
	9781209PW	White
	9781209PT	Almond
	9781209PB	Black
	9780265	Screw, 10 x 3/8
5		Glass, Door
	9781244	White
	9781245	Almond
	9781243	Black
6		Vent, Door
	9751242GW	White
	9751242GB	Black
	9751242GT	Almond
	9781072	Screw (2) 10AB x 1/2
	9781490	Seal, Door
	9781450	Gasket, Vent
7	9781453	Spacer, Door Vent
8		Handle, Door
	4212069	White
	4421442	Almond
	4212058	Black
	9781072	Screw (2) 10 x 1/2 (2)
9	9781449	Gasket, Door Glass
10	9750234	Hinge, Door R or L
	9780265	Screw (4) 10 x 3/8
11	9750693	Heat Channel
	9780265	Screw (2) 10 x 3/8
12	9750634	Baffle, Glass
13	9750233	Shield Door
14	9780771	Bumper, Rubber
15	9751245	Window Pack
16	9751135	Seal, Glass
	9780271	Screw (2) 8 x 1/4
18	9750231	Insulation
19	9781197GM	Liner, Door
20	9780583	Drawer & Roller
21	9750169	Bracket, Drawer
	9780272	Screw (4) 10 x 1/2
24		Front, Drawer
	4211992	White
	4211993	Almond
	4212056	Black
25	423713	Support, Roller
	90296	Clip
27	9781206	Retainer, Glass

OVEN CHASSIS PARTS

For Model: KGRT507FWH0, KGRT507FAL0, KGRT507FBL0
(White) (Almond) (Black)




NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4454392	Module, Spark
	9780269	Screw
	98997	Clip
2	4212002	Chassis, Front
5	9752651GM	Oven Liner
6	9750247	Gasket Oven
7		Oven, Side L or R
	4211896	White
	4211897	Almond
	4211895	Black
	9780265	Screw (4) 10 x 3/8
8	9780664	Shield, Insulation
	9780265	Screw (2)
9	9751789	Fan Duct, Side
	9780265	Screw, (4)
11	9752637	Burner Box
	9780269	Screw, #8-32 x 3/8
	9780265	Screw (8) 10 x 3/8
	9780275	Screw, (2) 8 x 3/8
12	9752735	Retainer, Insulation
	9780265	Screw (9) 10 x 3/8
13	9751653	Duct, Top
	9780265	Screw, (2)
14	9751060	Support, Fan
15	9750223	Drawer Rail, Left 10 x 3/8
	9750224	Drawer Rail, Right
	9780265	Screw (2) 10 X 3/8
16	9751020	Motor, Fan
	9751808	Screw, (3) #8 x 1"
17	9750147	Bottom Rail (2)
	9780265	Screw, (8) 10 x 3/8
18	312701	Foot, (4)
19	9750149	Hinge, Door L or R
	9780265	Screw, (2) 10 x 3/8
	9780270	Screw, (2) 8 x 3/8
20	421771	Support Rail, Pan
	9780265	Screw, (2) 10 x 3/8
21	9781025	Shield, Drawer
	9780265	Screw, 10 x 3/8
22	9751641	Plate, Reflectance
	9780265	Screw, 10 x 3/8
25	9751592	Vent Tube
	9780265	Screw, 10 x 3/8
29	9750897	Door Switch

BROILER & OVEN BURNER PARTS

For Model: KGRT507FWH0, KGRT507FAL0, KGRT507FBL0
(White) (Almond) (Black)




NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	9752737	Shield, Oven (2)
	9751643	Screw,
2	9752738	Flame Shield, Bake
	9751643	Screw, 10-3/8 (2)
3	9751424	Burner, Broiler
	9751644	Screw, 10-24x1/2
4	9751367	Burner, Bake
5	9751784	Ignitor, Broiler Burner
	9751643	Screw, 10-24x3/8
6	9751123	Ignitor, Oven Burner
	9751643	Screw, 10-24x3/8
7	9751168	Bracket, Broil Shooter
	9751203	Nut, 5/8 x 18
	9780265	Screw, 10 x 3/8
8	9752736GM	Pan, Oven Bottom
9	9751173	Tubing, Broil
10	9752698	Valve & Regulator Assembly
	776593	Screw, 1/4-20x1/2
12	9781015	Tubing, Valve To Regulator
13	9752734	Pan Support, Bake
14	9751600	Bracket, Bake
	9751643	Screw, 10-24x3/8
15	9751203	Nut #18 5/8
16	9752041	Bracket, Gas Broiler
	9780265	Screw
17	9752716	Orifice #54
18	9781508	Bracket, Broil Ignitor

OVEN PARTS

For Model: KGRT507FWH0, KGRT507FAL0, KGRT507FBL0
(White) (Almond) (Black)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	9781543	Assembly, Fan
	9780272	Screw, #10 x 1/2
4	4173237	Nut
5	9751117	Fan
6	4173238	Shim Ring
9	9751904GM	Baffle, Convection
	9780270	Screw, (2) 8 x 3/8
10	4167277	Lock-Nut, Cvr.Jack
11	4167266	Jack Cover
12	4163975	Gasket
13	4173575	Receptacle, Probe
14	3179672	Spacer, Tubing
15	4211947	Bulb, Oven
16	9781050	Light, Socket
17	3150144	Probe
18	4421424	Grill, Broiler
19	4211944	Pan, Broiler
20	3181534	Rack, Roasting
21	9750823	Rack, Standard (3)
22	3148440	Sensor
	9781509	Screw 8-32 x 3/8
23	9781049	Lens, Light
24	3184533	Gasket, Lens

REAR CHASSIS PARTS

For Model: KGRT507FWH0, KGRT507FAL0, KGRT507FBL0
(White) (Almond) (Black)



NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	9751051	Back, Chassis
	4211813	Screw (4)
	340184	Screw (2)
3	9751353	Panel, Rear Cover
	4211813	Screw (2)
5	9751418	Bracket, Lock
	9780265	Screw (2)
6	9751500	Bracket, Regulator Valve
7	9751439	Oven Lock Assy.
	9780265	Screw (2)
8	9751590	Solenoid
	4211945	Screw (2)
	4211875	Washer
12	9751763	Switch, Interlock
	9750887	Screw (2)
	9750888	Nut (2)
15	9750523	Rod, Lock
16	9780881	Ballast, Lamp
	9780265	Screw (2)
17	258076	Block, Terminal
	98884	Screw (2)
	422667	Clip, Tube

OPTIONAL PARTS

SPLICING WIRES--25FT. LENGTH

242828	Wire, Black 12 Ga. 150~c
242820	Wire, Black 14 Ga. 150~c
242821	Wire, Blue 14 Ga. 150~c
242822	Wire, Brown 14 Ga. 150~c
242830	Wire, Brown 14 Ga. 200~c
242823	Wire, Green 14 Ga. 150~c
242824	Wire, Orange 14 Ga. 150~c
242829	Wire, Red 12 Ga. 150~c
242825	Wire, Red 14 Ga. 150~c
242831	Wire, Red 14 Ga. 200~c
242826	Wire, White 14 Ga. 150~c
242827	Wire, Yellow 14 Ga. 150~c
242832	Wire, Yellow 14 Ga. 200~c

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
72109	New Avocado
72108	Coffee
72110	Harvest Gold
72112	Toast
72113	Platinum
511873	**White Porcelain (2 Oz.)

**Note: Cooktop Surface is Porcelain; All Other Panels are Painted Surfaces.

PAINT, PRESSURIZED SPRAY (13 oz.)

350930	White
--------	-------

350956	Almond
261888	New Avocado
261886	Coffee
261890	Harvest Gold
285365	Toast
285366	Platinum
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)
261891	Harvest Gold (Uncut)
285367	Toast (Uncut)
285368	Platinum (Uncut)

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean (1/2 Pt.)

INSULATION

9751164	Insulation, Wrap
9750221	Insulation, Rear
9751323	Insulation, Bottom

CLEANER, COOKTOP

3184477	Glass Cleaner
3183488	Scraper

ACCESSORIES

241430	Foil, Aluminum Oven (18" X 25')
--------	---------------------------------

CONVERSION KIT

	Gas Conversion Kit
9751844	LP
9752717	Natural

LUBRICANT

261582	Grease
--------	--------

ANTI-TIP KIT

9751745	Anti-Tip Kit
---------	--------------

LITERATURE PARTS

LIT9752397	Installation Instructions
LIT9780959	Convection Cookbook
LIT9752684	Use & Care Guide
LIT9752686	Smart & Easy Guide
LIT9752669	Tech Sheet
LIT9752668	Wiring Diagram

WIRING HARNESS PARTS

3190207	Harness, Wire (Main Harness)
9751708	Harness, Wire (Neutral Gas)
3190208	Harness, Wire (Spark Control)
9751139	Harness, Wire (Meat Probe)
9750376	Harness, Wire (Oven Door)

9751750	Harness, Wire (Flourescent)
9752769	Harness, Wire (Spark Module)
9752770	Jumper, Burner (4)
20082084	Tie, Wire
9751868	Grommet Harness (2)
9781055	Power Cord